FOXGUARD

ADVANCED "HI-TECH"
SECURITY SYSTEMS

HI007

ULTRASLIM

STANDALONE
ANTI-HIJACK



INDEMNITY

Foxguard Electronics PTY (LTD). indemnifies itself against any claims or damages arising directly or indirectly from the use of any of its immobilize devices and/or failure due to design, manufacture, quality, components, recommended installation techniques and/or any consequential claims by third party, accident, fire, theft, insurance or vehicle manufacturers guarantees or for any reason whatsoever that may arise from the use or installation of its products.

Anti Hijack

Anti Hijack button has to be pressed every time the vehicle is started to cancel Anti Hijack. If door is opened or button was not pressed when the vehicle was started the LED will flash twice to indicate Anti Hijack sequence will start in 1 minute. After 1 minute a audible warning will be given to indicate Anti Hijack has started. Flashing indicators for 20 seconds will follow. Then flashing indicators , siren and temporally ignition cut will follow for another 30 seconds before the vehicles ignition will be cut. To **clear Anti Hijack**, press **hijack button** for **2 second**. If the Anti Hijack sequence is canceled the LED will flash 6 times.